

**PULSANTE ALIMENTAZIONE  
 POUSSOIR ALIMENTATION – ZUFUHRDRUCKKNOPF  
 FEEDING PUSH BUTTON BOTON ALIMENTACION  
 INDICATORE LIVELLO  
 INDICATEUR NIVEAU – PEGELANZEIGER  
 LEVEL INDICATOR – INDICATOR NIVEL**

1	<b>010071</b>	MS/ES 100	CORPO P. ALIMENT.	CORPS POUS. ALIM.	KOPER ZUFUHRDR.	BODY FEEDING P.	CUERPO BOT. ALIM.
2	<b>010101</b>	MS/ES 100	RACCORDO A "T"	RACCORD T	T AHSCHLUSS	T JOINT	T UNION
3	<b>100021</b>	MS/ES 100	RACCORDO P. ALIM.	RACCORD	AHSCHLUSS	JUNCTION	UNION
4	<b>100102</b>	MS/ES 100	ASTINA COMANDO	TIGE	STANGE	ROD	VARILLA
5	<b>100020</b>	MS/ES 100	POMOLO COM. P. A.	LEVIER	HEBEL	LEVEL	FULCRO
6	<b>100022</b>	MS/ES 100	PORTAPAST. P. A.	PORTE JOINT	SCHEIBENHALTER	PAD-HOLDER	PORTA PASTILLA
7	<b>160003</b>	MS/ES 100	MOLLA P. A.	RESSORT	FEDER	SPRING	RESORTE
8	<b>150004</b>	MS/ES 100	GUARNIZIONE P. A.	JOINT	DICHTUNG	GASKET	PASTILLA
9	<b>190020</b>	MS/ES	PASTIGLIA	JOINT ROBINET	HAHNDICHTUNG	COCK GASKET	JUNTA GRIFO
10	<b>170603</b>	MS/ES	DADO M 6	ECROU	MUTTER	NUT	TUERCA
11	<b>190013</b>	MS/ES 100	OR PER P. ALIM.	JOINT OR	OR DICHTUNG	OR GASKET	JUNTA OR
12	<b>170502</b>	MS/ES	VITE TCB M 5 x 12 TR	VIS	SCHRAUBE	SCREW	TORNILLO
13	<b>050001</b>	MS/ES 60	TUBO TREC. mm 500	TUBE FLEX	ROHR FLEX	PIPE FLEX	TUBO FLEX
	<b>050003</b>	MS/ES 70	TUBO TREC. mm 800	TUBE FLEX	ROHR FLEX	PIPE FLEX	TUBO FLEX
	<b>050005</b>	MS/ES 100/2	TUBO TREC. mm 1000	TUBE FLEX	ROHR FLEX	PIPE FLEX	TUBO FLEX
	<b>050007</b>	MS/ES 100/3	TUBO TREC. mm 1200	TUBE FLEX	ROHR FLEX	PIPE FLEX	TUBO FLEX
	<b>050009</b>	MS/ES 100/4	TUBO TREC. mm 1500	TUBE FLEX	ROHR FLEX	PIPE FLEX	TUBO FLEX
14	<b>010041</b>	MS/ES	PIPA LIVELLO	PIPE NIVEAU	PEGEL ANSCHLUSS	LEVEL PIPE	PIPETA NIVEL
15	<b>100030</b>	MS/ES	DADO BASSO 3/8	ECROU BAS	NIEDR MUTTER	LOW NUT	TUERCA BAJA
16	<b>130001</b>	MS/ES 100	CUSTODIA LIVELLO	SUPPORT NIVEAU	PEGELWINKEL	LEVEL SUPPORT	SUPPORT NIVEL
17	<b>100163</b>	MS/ES 100	DADO LIVELLO	BOUCHON NIVEAU	PEGELVERSCHLUSS	LEVEL CAP	TAPON NIVEL
18	<b>050013</b>	MS/ES	TUBO SCARICO	TUBE	ROHR	PIPE	TUBO
19	<b>100026</b>	MS/ES 100	RONDELLA LIVELLO	RONDELLE	SCHEIBE	WASHER	ARANDELA
20	<b>190006</b>	MS/ES	OR PER RUBINETTO	JOINT OR	OR DICHTUNG	OR GASKET	JUNTA OR
21	<b>030100</b>	MS/ES 100	SFERA PER LIVELLO	BILLE NIVEAU	PEGELKUGEL	LEVE GLASS	ESPERA NIVEL
22	<b>190025</b>	MS/ES 100	GUARN. LIVELLO	JOINT PTFE	PTFE DICHTUNG	PTFE GASKET	PASTILLA PTFE
23	<b>210001</b>	MS/ES 101	VETRO LIVELLO	VERRE NIVEAU	PEGELGLASS	LEVEL GLASS	VIDRIO NIVEL
24	<b>050011</b>	MS/ES	TUBO ALIMENTAZIONE 3/8 - 3/8	TUBE PLEX 3/8 - 3/8	ROHR FLEX 3/8 - 3/8	PIPE FLEX 3/8 - 3/8	TUBO 3/8 - 3/8
25	<b>050012</b>	MS/ES	TUBO ALIMENTAZIONE 3/4 - 3/8	TUBE PLEX 3/4 - 3/8	ROHR FLEX 3/4 - 3/8	PIPE FLEX 3/4 - 3/8	TUBO 3/4 - 3/8
	<b>900004</b>	MS/ES 100	LIVELLO COMPLETO	INDICATEUR NIVEAU	PEGELANZEIGER	LEVEL INDICATOR	INDICATOR NIVEL
	<b>900005</b>	MS/ES 100	PULS. ALIM. COMPL.	POUSSOIR ALIM.	ZUFUHRDRUCK.	FEEDINGPUSH BUT.	BOTON ALIM.

